



KERN & Sohn GmbH

Ziegelei 1

D-72336 Balingen

E-Mail: info@kern-sohn.com

Phone: +49-[0]7433- 9933-0

Fax: +49-[0]7433-9933-149

Internet: www.kern-sohn.com

Operating manual Electronic Crane Scales

Logbook
Regular maintenance and care

KERN HFA

Version 1.3

2018-02

GB



HFA-BA-e-1813



KERN HFA

Version 1.3 2018-02

Operating instructions / logbook Electronic Suspended balance

Contents

1.	Technical data	4
1.1	Dimensions	6
1.2	Nameplate	8
1.3	EC-Declaration of -Conformity	9
2.	General Safety Instructions	10
2.1	Duties of the owner-operator	10
2.2	Organizational measures	10
2.3	Environmental conditions	10
2.4	Pay attention to the instructions in the Operation Manual	11
2.5	Proper use	11
2.6	Improper Use	11
2.7	Warranty	11
2.8	Safe working	12
2.9	Monitoring of Test Resources	12
2.10	Testing upon acceptance	12
2.11	Initial Commissioning	12
2.12	Shutdown and storage	12
3.	Appliance overview	13
3.1	Overview of display	15
3.2	Keyboard overview	16
3.3	Label	17
4.	Commissioning	18
4.1	Unpacking	18
4.2	Scope of delivery	18
4.3	Checking the original dimensions	19
4.4	Battery / rechargeable battery operation	19
4.6	Suspending the balance	22
5.	Operation	23
5.1	Safety instructions	23
5.2	Loading the suspended balance	24
5.3	Turn on/off	27
5.4	Set balance to zero	27
5.5	Taring	27
5.6	Weighing	28
5.7	Switch-over weighing unit	28
5.8	Hold weighing value (Data-HOLD function)	29
5.9	Peak value function (peak function)	29
5.10	Weighing with tolerance range	30
5.11	Automatic switch-off function (auto-off)	32


6.	Menu	32
6.1	Navigation in the menu:	32
6.2	Overview	33
7.	Adjustment	34
8.	Linearization	36
8.1	Linearization	36
8.2	Carry out linearization	37
9.	Cleaning, Repair, Maintenance and Disposal	39
9.1	Cleaning and Disposal	39
9.2	Regular maintenance and care	40
9.3	Checklist „regular maintenance“, (see chapter 9.2)	41
10.	Enclosure	43
10.1	Checklist „Enhanced maintenance“ (General revision)	43

1. Technical data


KERN	HFA 600K-1	HFA 1T-4	HFA 3T-3
Readability (d)	0.2 kg	0.5 kg	1 kg
Weighing range (max)	600 kg	1000 kg	3000 kg
Taring range (subtractive)	599.8 kg	999.5 kg	2999 kg
Reproducibility	0.2 kg	0.5 kg	1 kg
Linearity	± 0.4 kg	± 1 kg	± 2 kg
Recommended adjustment weight, not added (class)	600 kg (M3)	1000 kg (M3)	3000 kg (M3)
Stabilization time	2 s		
Warm-up time	10 min		
Units	kg, lb, N		
Auto off	10 min		
Allowable ambient temperature	5...+35 °C		
Ambient humidity (max)	80 %		
Input Voltage	Power supply unit 100 – 240 V, 50 / 60 Hz		
	Device 9 V, 800 mA		
Battery	3 x 1.5 V AA		
	Service life (background illumination OFF) 30 h		
Rechargeable battery NiMH	Service life (background illumination OFF) 30 h		
	Loading time 12 h		
Display	Digit height 2.3 cm		
Housing material	Steel		
Net weight	1700 g		

KERN	HFA 5T-3	HFA 10T-3
Readability (d)	2 kg	5 kg
Weighing range (max)	5000 kg	10000 kg
Taring range (subtractive)	4998 kg	9995 kg
Reproducibility	2 kg	5 kg
Linearity	± 4 kg	± 10 kg
Recommended adjustment weight, not added (class)	3000 kg (M3)	10000 kg (M3)
Stabilization time	2 s	
Warm-up time	10 min	
Units	kg, lb, N	
Auto off	10 min	
Allowable ambient temperature	5...+35 °C	
Ambient humidity (max)	80 %	
Input Voltage	Power supply unit 100 – 240 V, 50 / 60 Hz	
	Device 9 V, 800 mA	
Battery	3 x 1.5 V AA	
	Service life (background illumination OFF) 30 h	
Rechargeable battery NiMH	Service life (background illumination OFF) 30 h	
	Loading time 12 h	
Display	Digit height 2.3 cm	
Housing material	Steel	
Net weight	3900 g	5500 g


1.1 Dimensions



Balance 5 t



Balance 10 t



1.2 Nameplate



①	KERN Logo
②	Model designation
③	Weighing range [Max]
④	Data for power supply
⑤	Company address
⑥	Readability [d]
⑦	Date of manufacture
⑧	CE mark
⑨	Disposal symbol
⑩	Serial number

1.3 EC-Declaration of -Conformity



KERN & Sohn GmbH
Ziegelei 1
72336 Balingen-Frommern
Germany

www.kern-sohn.com
+0049-[0]7433-9933-0
+0049-[0]7433-9933-149
info@kern-sohn.com

Déclaration de conformité UE | EU Declaration of Conformity | EU-Konformitätserklärung

FR Nous déclarons par la présente sous notre entière responsabilité que le produit concerné par cette déclaration respecte les exigences des directives mentionnées ci-après.

EN We hereby declare and assume sole responsibility for the declaration that the product complies with the directives hereinafter.

DE Wir erklären hiermit unter alleiniger Verantwortung, dass das Produkt, auf das sich diese Erklärung bezieht, mit den nachstehenden Richtlinien übereinstimmt.

Type | Type | Typ

N° de série | Serial no. | Seriennr.

HFA 600K-1K50
HFA 1T-4
HFA 3T-3
HFA 5T-3
HFA 10T-3

XXXXXXXXXX

Marquage CE Mark applied CE Kennzeichnung	Directive UE EU directive EU-Richtlinie	Normes Standards Normen
	2006/42/EC (MD)	EN 13155:2003/A2:2009
	2014/30/EU (EMC)	EN 55022:2010 EN 55024:2010 EN 61000-3-3:2013
	2014/35/EU (LVD)	EN 60065:2014 EN 60950-1:2006/A2:2013

Date | Date | Datum: 06.10.2016

Lieu de délivrance: 72336 Balingen,
Place of issue: Germany

Ort der Ausstellung:

Albert Sauter
KERN & Sohn GmbH

Signature: Directeur Exécutif
Signature: Managing director
Signatur: Geschäftsführer

i Further language versions you will find online under:

www.kern-sohn.com/ce

2. General Safety Instructions

2.1 Duties of the owner-operator

Follow national accident prevention regulations and all operator health and safety at work and operating regulations.

- Observe all safety regulations of the crane manufacturer.
- The balance may only be used for the proposed purpose. Any type of use which is not specified in these operating instructions, will be considered as improper use. The customer is solely responsible for material damage and injury of persons resulting from an improper use, Messrs. KERN & Sohn will not be liable under any circumstance.

Messrs. KERN & Sohn cannot be held liable, if the suspended balance is modified or used improperly and if damage is resulting from such use.

- Carry out service and repair to suspended balance (see chap. 9.3), crane and lifting tackle at regular intervals.
- Log the test result and keep it in the logbook.

2.2 Organizational measures

- Only trained and instructed staff may operate the balance.
- Make sure that the operating instructions are kept nearby the operation site of the suspended balance.
- Assembly, commissioning and maintenance should only be carried out by trained specialists.
- Weight-bearing components must not be replaced.

2.3 Environmental conditions

- Never operate suspended balance in spaces exposed to explosion hazards. The serial version is not explosion protected.
- Operate the suspended balance only under environmental conditions as specified in these operating instructions (especially in chapter 1 „Technical data“).
- Do not expose the suspended balance to strong humidity. Non-permitted condensation (condensation of air humidity on the appliance) may occur if a cold appliance is taken to a considerably warmer environment. In this case, acclimatize the disconnected appliance for ca. 2 hours at room temperature.
- Do not use suspended balance in environments exposed to corrosion hazards.
- Protect the suspended balance against high humidity, vapours and dust.
- Major display deviations (incorrect weighing results) may be experienced should electromagnetic fields (e.g. due to mobile phones or radio equipment), static electricity accumulations or instable power supply occur. Change location or remove source of interference.

2.4 Pay attention to the instructions in the Operation Manual



- ⇒ Carefully read this operation manual before setup and commissioning, even if you are already familiar with KERN balances.
- ⇒ All language versions contain a non-binding translation. The original German is binding.

2.5 Proper use

The balance you purchased is intended to determine the weighing value of material to be weighed. It is intended to be used as a “non-automatic” balance, i.e. the material to be weighed is suspended on the load receptor only vertically, manually, carefully and without jerks. As soon as a stable weighing value is reached the weighing value can be read.

- Use the suspended balance only for lifting and weighing of freely movable loads.
- Danger of injury due to improper use. Not allowed are e.g.:
 - Exceeding the allowed nominal load of crane, suspended balance or any type of load attachment devices
 - Conveying persons,
 - Pulling loads over an inclined surface,
 - Tearing-off, pulling or towing loads.
- Modifications or reconstructions of the suspended balance or of the crane are not allowed.

2.6 Improper Use

Do not use balance for dynamic weighing. In the event that small quantities are removed or added to the material to be weighed, incorrect weighing results can be displayed due to the “stability compensation”. (Example: Slowly draining fluids from a container suspended on the balance.) Do not leave permanent load suspended on the balance. This may damage the measuring system as well as safety-relevant parts.

The balance may only be used according to the described conditions. Other areas of use must be released by KERN in writing.

2.7 Warranty

Warranty claims shall be voided in case

- Our conditions in the operation manual are ignored
- The appliance is used outside the described uses
- The appliance is modified or opened
- Mechanical damage and damage caused by media, liquids,
- Natural wear and tear
- The appliance is improperly set up or incorrectly electrically connected
- The measuring system is overloaded

2.8 Safe working

- Do not stand under swinging loads, see chap. 5.1.
- Position the crane in a way that the load is lifted vertically.
- When working with the crane and suspended balance wear personal safety equipment (helmet, safety shoes etc.).

2.9 Monitoring of Test Resources

In the framework of quality assurance the measuring-related properties of the balance and, if applicable, the testing weight, must be checked regularly. The responsible user must define a suitable interval as well as type and scope of this test. Information is available on KERN's home page (www.kern-sohn.com) with regard to the monitoring of balance test substances and the test weights required for this. In KERN's accredited DKD calibration laboratory test weights and balances may be calibrated (return to the national standard) fast and at moderate cost.

2.10 Testing upon acceptance

Inspect packaging immediately upon receipt and inspect device when unpacking (see chap. 4.1.) in the event of any evident damage.

2.11 Initial Commissioning

In order to obtain exact results with the electronic balances, your balance must have reached the operating temperature (see warming up time chap. 1).

During this warming up time the balance must be connected to the power supply (mains, accumulator or battery).

The accuracy of the balance depends on the local acceleration of gravity.

Strictly observe hints in chapter Adjustment.

For checking original dimensions, s. chap. 4.3

2.12 Shutdown and storage

- Remove suspended balance from crane and remove all attachment devices from the suspended balance.
- Do not store suspended balance outdoors.

3. Appliance overview





- 1 Anchor eyelet
- 2 Display
- 3 Keyboard







**Lifting tackle not included in scope of delivery.
Standardised attachment devices are to be used to attach loads.**

Rear


	
<p>Battery or rechargeable battery compartment</p>	<p>Mains connection</p>






3.1 Overview of display



Display	Significance
	Rechargeable battery capacity
  	Indicators for weighing with tolerance range
M+	Totalization
STABLE	Stability display
ZERO	Zero indicator
Net	The displayed weighing value is a net weighing value
OZT Lb kg	Weighing Units

3.2 Keyboard overview



Button	Description of function
	<ul style="list-style-type: none"> • Taring • Zeroing • Exit menu / back to weighing mode.
	<ul style="list-style-type: none"> • Switch-over weighing unit • Scroll up/down menu • For numeric entry increase value of digit • Set readability (options: 1d/2d/5d/10d/20d)
	<ul style="list-style-type: none"> • Set weight display • Set peak load • Confirm
	<ul style="list-style-type: none"> • Switch over weighing unit (kg→lb→N) • Select digits for numeric entry
	<ul style="list-style-type: none"> • Turn on/off balance

3.3 Label



- ⇒ Do not stand or go under suspended loads.
- ⇒ Do not use on building site.
- ⇒ Keep an eye on suspended loads.





- ⇒ Do not exceed nominal rated load of balance.

(example)








- ⇒ The product conforms to the requirements of the German Equipment and Product Safety Act.

4. Commissioning

	 Always observe chapter 2 „General Safety Instructions“!
---	--

4.1 Unpacking

 SAFETY INSTRUCTIONS for protection against break	Once delivered and unpacked, suspended balances will not be taken back.
	 The crane scales have been sealed by Messrs. KERN.  Removal from packaging is also sealed.  Broken seal obliges to purchase.  Fig.: Seal
	Thanks for your comprehension. Your KERN Quality assurance team


4.2 Scope of delivery

Remove balance and accessories from packaging, remove packaging material. Verify that there has been no damage and that all packing items are present.

- For crane see chap. 3.0
- Rechargeable battery (3 x 1.5 V AA)
- Operating instructions / logbook

4.3 Checking the original dimensions


- ⇒ Enter the original dimensions shown on the production data sheet in the grey boxes of checklist chap. 9.3.
- ⇒ Check original dimension of suspended balance; for implementation see chap. 8.3 „Regular Maintenance“
- ⇒ Enter all data (date, tester, results) in the first line under „Inspection before first use“ in the checklist (see chapter 9.3)

 CAUTION	<p>If the dimensions of your first safety inspection do not match those of KERN, the balance must not be put into operation. In this case please contact a service partner authorised by Messrs. KERN.</p>
---	--

4.4 Battery / rechargeable battery operation

Battery operation:



When batteries are empty,  will appear on the balance's display

Press  and replace batteries.


Open battery compartment, replace batteries and close battery compartment again.


In order to save the battery, the balance switches automatically off after 4 minutes without weighing. This auto-off function can be deactivated in the menu, see chap. 6.

When the suspended balance is out of operation for a longer period, remove the batteries.

<p>Unscrew battery / rechargeable battery compartment in the direction of the arrow.</p>	
<p>Replace batteries and relock battery / rechargeable battery compartment.</p>	

Accu operation:

When the rechargeable battery is empty,  appears on the balance's display. Turn off balance and connect power supply unit; battery is charged.

Once the battery has been fully charged the display will show the  symbol.

Insert rechargeable battery:


Unscrew battery compartment in arrow direction.



Remove batteries including battery mount from the device.




Connect cable of balance to battery cable as shown on image.



Insert battery in the centre.
Ensure that the cables are not kinked.
Relock battery compartment.



4.6 Suspending the balance



Condition

The crane needs a safety bracket (1) that the unloaded suspended balance cannot fall down.





If the safety bracket is missing or damaged, please contact the crane manufacturer in order to receive a hook with this safety equipment.

⇒ Attach the suspended balance to the lower hook of a crane and close the safety bracket.

The crane scale's upper eyelet should rest in the saddle (2).

5. Operation

5.1 Safety instructions

	 <p>Risk of injury due to falling loads!</p>
  <p>(example)</p>	<ul style="list-style-type: none"> ⇒ Take great care when operating the crane and follow the general rules for crane operation. ⇒ Check all parts (hook, carabines, rings, rope slings, cables, chains etc.) for excessive wear or damage ⇒ If faults can be seen on the safety bracket of the crane hook or if it is missing completely, the scales must not be used. ⇒ Work only with appropriate speed ⇒ Always avoid vibrations and horizontal forces. Avoid any kind of shock, torsion and oscillating (e.g. caused by inclined suspending) ⇒ Do not use the suspended balance for conveying loads. ⇒ Do not stand or go under suspended loads. ⇒ Do not use on building site. ⇒ Keep an eye on suspended loads. ⇒ Do not exceed nominal rated load of crane, suspended balance or any kind of attachment device on the suspended balance. ⇒ For weighing dangerous goods (e.g molten masses, radioactive materials) the “Dangerous Goods Regulations” are to be regarded!

5.2 Loading the suspended balance


For good weighing results observe the following, illustrations see next page:


- ⇒ Only use load attachment devices which guarantee a one-spot suspension and where the scales can be suspended freely.
- ⇒ Do not use too large load attachment devices which do not guarantee any one-spot suspension.
- ⇒ Do not use multiple suspensions.
- ⇒ Do not pull or push the load or the loaded balance.
- ⇒ Do not pull the hook horizontally.

Loading the balance

1. Position the hook of the suspended balance over the load.
2. Move downwards the suspended balance until the load can be suspended on the hook of the balance. Reduce the speed when the respective height is going to be reached.
3. Attach load to attachment device. Ensure that all safety-relevant devices are functional (e.g. the safety latch is closed). If the load is fixed by slings, ensure that the slings rest completely on the saddle of the balance hook.
4. Lift-off the load slowly.


When the load is fixed by slings, ensure that the load is well balanced on both sides and that the slings are correctly positioned

 Always use suitable lifting tackle.




Only use attachment devices which guarantee a one-point suspension and where the scales can be suspended freely.

Do not use too large attachment devices which cannot guarantee a one-point suspension.



5.3 Turn on/off

Start-up

- ⇒ Press . The display lights up and the balance carries out a selftest. As soon as the weight display appears, the instrument will be ready to weigh.


Switching Off


- ⇒ Press .

5.4 Set balance to zero

In order to obtain optimal weighing results, reset to zero the balance before weighing.


- ⇒ Unload the balance


- ⇒ Press , zero display as well as indicator **ZERO** will appear.




5.5 Taring

- ⇒ Attach initial load.


Press  until zero display appears. The weight of the container is now internally saved.



- ⇒ Weigh the material, the net weight will be indicated.
- ⇒ After removing the preload weight appears as negative display.
- ⇒ To delete the tare value, remove load from suspended balance and press .

5.6 Weighing

- ⇒ Load the suspended balance.
The weight value will be displayed at once.




Overload warning

Overloading exceeding the stated maximum load (max) of the balance, minus a possibly existing tare load, must be strictly avoided. This could cause damage to the balance. Exceeding the maximum load is indicated by the display „ol“. Unload balance or reduce preload.

5.7 Switch-over weighing unit

The next weighing unit **kg**→**N**→**lb** will be displayed after each press of the **UNIT** button.

The indicator ▼ above N shows weight in Newton.





In menu item “F2 UNT“, weighing units “N“ and “lb“ can be turn on or off.


5.8 Hold weighing value (Data-HOLD function)

Once a stable weight value has been established, this can be fixed until deleted before the next weighing activity.

⇒ Attach the material to be weighed

⇒ To start the Hold function, press  and the heaviest load of the last weighing activity will be displayed.
The indicator ▼ above HOLD appears.




⇒ The weighing value will be held in the display until it is deleted by .


5.9 Peak value function (peak function)



Attention:



Never exceed the maximum permitted load of the peak value on the balance (!!Danger of breaking!!).

⇒ To start the peak value function, press and hold  during zero display.
⇒ Lift load and the heaviest load of the weighing activity will be displayed.
The indicator ▼ above **PEAK** will appear.






⇒ The peak load will be held on the display until deleted by pressing . For that, press  for about 2-3 seconds. The ▼ above **PEAK** disappears.

5.10 Weighing with tolerance range









To ensure that your weight value is within a defined tolerance range, you can define an upper and a lower limit value of your choice using function "F3 chk" (See chap. 6). During tolerance tests such as portioning or sorting the unit will indicate exceeded or undershot limits by emitting an optical or acoustic signal.











Optical signal:

The optical signals provide the following information:

	Load exceeds specified tolerance
	Load within specified tolerance
	Load below specified tolerance




Call up function "F3 chk":

1. Switch-on balance and during the selftest press .
The first function „F0bk“ is displayed.
2. Press  repeatedly until "F3 chk" will be displayed.
3. Press , the display used for entering the lower limit „Ck Lo“ appears.
4. Press  again, the currently set lower limit value is displayed. The active digit is flashing. Press  to select the digit to be amended.
To change the selected (flashing) digit, press  repeatedly until the desired value is displayed.
5. Confirm entry by , "Ck Lo" will appear.
6. Press , the display used to enter the upper limit value "Ck Hi" will appear.

7. Acknowledge by .
8. Press  again, the currently set upper limit value is displayed. The active digit is flashing. Press  to select the digit to be amended.
To change the selected (flashing) digit, press  repeatedly until the desired value is displayed.
9. Confirm entry by , "Ck Hi" will appear.
10. Press , the display used to set the audio signal "bEEP" will appear.
11. Press , the current setting for the acoustic signal will be shown.
12. Select desired setting (bp 1, bp 2, bp 3) by  and confirm by .
13. Press  repeatedly to exit menu. From here evaluation takes place whether the goods to be weighed are within the two tolerance limits.

Start tolerance check:

⇒ Tare when using a weighing container.
Put on goods to be weighed, tolerance control is started. The signal lights indicate whether the load is within the two set limits.

Load below specified tolerance	Load within specified tolerance	Load exceeds specified tolerance
 <p>The indicator [LO] appears</p>	 <p>The indicator [OK] appears</p>	 <p>The indicator [HI] appears</p>

i







- The tolerance control is not active when the weight is under 20d.
- To delete limits, enter "0000 kg".

5.11 Automatic switch-off function (auto-off)

The automatic switch-off function allows you to set a period of time in the menu after that the balance will switch off automatically in stand-by mode.

6. Menu

6.1 Navigation in the menu:

Call up menu	⇒ Switch-on balance and during the selftest press  . The first function F0bk is displayed.
Select menu item	⇒ With help of  , the individual menu items can be selected one after the other.
Select setting	⇒ Confirm selected menu item by pressing  . The current setting will be displayed.
Change settings	⇒ Switch into the available settings using  .
Confirm setting	⇒ Press  , balance returns to menu
Exit menu / Return to weighing mode	⇒ Press  repeatedly.

6.2 Overview










Function	Available settings	Description	
F0 bk Display background illumination	bk on	Background illumination on	
	bk off	Background illumination off	
	bk AU	Background illumination switches on automatically when loaded or a button is pressed	
F1 AZ Autozero	AZ 0.5d	Automatic zero correction (auto-zero) on change of display, Selectable digits available 0.5d, 1d, 2 d, 4 d.	
	AZ 1d		
	AZ 2d		
	AZ 4d		
F2 Unt Standard weighing unit	Ut lb	Pound	
	Ut kg	Kilogram	
	Ut N	Newton	
F3 CHk Check weighing	Ck Lo	Lower limit value, input see chap. 5.9	
	Ck Hi	Upper limit value, input see chap. 5.9	
F4 CAP Capacity	1000 kg	Weighing range [Max], options 1000 / 2000 / 3000 / 5000 / 10000 kg	Modifications may only be carried out by a specialist with competent knowledge.
	2000 kg		
	3000 kg		
	5000 kg		
	10 000 kg		
F5 CAL Adjustment / linearization	nonLi	Adjustment	
	Line	Linearization	
F6 isp	XXXXX	Internal A/D converter value	
F7 GrA	Not documented		
F8 rst	Reset to default setting		
F9SPd Display speed	SPd 7.5		
	SPd 15		
	SPd 30		
	SPd 60		
F10of Autom. switch-off function (auto off)	Off 0	Off 0: Autom. switch-off function disabled	
	Off 3	Off 3/5/15/30: Balance will switch off after x minutes in stand-by mode.	
	Off 5		
	Off 15		
	Off 30		














* = default setting

7. Adjustment

As the acceleration value due to gravity is not the same at every location on earth, each balance must be coordinated - in compliance with the underlying physical weighing principle - to the existing acceleration due to gravity at its place of location (only if the balance has not already been adjusted to the location in the factory). This adjustment process must be carried out for the first commissioning, after each change of location as well as in case of fluctuating environment temperature. To receive accurate measuring values it is also recommended to adjust the balance periodically in weighing operation.

- i**
- Provide the required adjustment weight, see chap. 1. "Techn. data". The weight to be used depends on the capacity of the scale. Carry out adjustment as near to maximum load as possible. Info about test weights can be found on the Internet at: <http://www.kern-sohn.com>
 - Observe stable environmental conditions. A warming up time (see chapter 1) is required for stabilization.

⇒ Turn off balance and attach suitable lifting tackle.	
⇒ Turn on balance with the lifting tackle attached and press  during self-test. The first function „F0bk“ is displayed.	
⇒ Press  repeatedly until „F5CAL“ is displayed.	
⇒ Press  , the last parameter set will be displayed. <ul style="list-style-type: none"> • „nonLi“ Adjustment of balance or • „LinE“ Linearisation of balance 	 
⇒ Select „nonLi“ by 	

<p>⇒ Press , "ULoAd" will be displayed. Make sure that no loads apart from the lifting tackle are attached to the hook.</p>	
<p>⇒ Wait for stability display, then press .</p>	
<p>⇒ Either use the displayed adjustment weight or change by  and , the currently enabled digit is flashing. Press  to select the digit to be amended. To change the selected (flashing) digit, press  repeatedly until the desired value is displayed.</p>	 (example)
<p>⇒ Confirm by , „LoAd“ will be shown.</p>	
<p>⇒ Attach adjustment weight. Wait for stability display, then press .</p>	
<p>⇒ After successful adjustment „Pass“ will be displayed. After that, the balance will carry out a self-test, followed by a brief display of "Err4". Finally the balance returns automatically to weighing mode, adjustment has been carried out successfully.</p>	  (example)

An adjusting error or incorrect adjusting weight will be indicated by the error message; repeat adjustment procedure.

8. Linearization

8.1 Linearization














Linearity shows the greatest deviation of a weight display on the scale to the value of the respective test weight according to plus and minus over the entire weighing range.








If linearity deviation is discovered during a monitoring of test resources, you can improve this by means of linearization.



- Carrying out linearization is restricted to specialist staff possessing well acquainted with the workings of balance.
- The test weights to be used must be adapted to the balance's specifications; see chapter 2.9 "Testing instruments control".
- Observe stable environmental conditions. Stabilisation requires a certain warm-up time.
- After successful linearization you will have to carry out calibration; see chapter 2.9 "Testing instruments control"


8.2 Carry out linearization

⇒ Turn off balance and attach suitable lifting tackle.	
⇒ Turn on balance with the lifting tackle attached and press  during self-test. The first function „F0bk“ is displayed.	
⇒ Press  repeatedly until „F5CAL“ is displayed.	
⇒ Press  , the last parameter set will be displayed. <ul style="list-style-type: none"> • „nonLi“ Adjustment of balance or • „LinE“ Linearisation of balance 	 
⇒ Select „LinE“ by 	
⇒ Press  , „LoAd 0“ will appear. Make sure that no loads apart from the lifting tackle are attached to the hook.	
⇒ Wait for stability display and press  again. „LoAd 1“ (1/3 max) will be displayed.	


<p>⇒ Attach first adjustment weight, wait for stability display</p> <p>Press , "LoAd 2" (2/3 max) will be displayed.</p>	
<p>⇒ Attach second adjustment weight, wait for stability display</p>	
<p>⇒ Press , "LoAd 3" (max load) will be displayed</p>	
<p>⇒ Attach third adjustment weight, wait for stability display</p>	
<p>⇒ Press , "PASS" will be displayed</p> <p>⇒ Finally the balance will carry out a self-test, "Err19" is briefly displayed (Ignore error message), then the balance returns automatically to weighing mode, the weight value is displayed and linearization has been completed successfully.</p>	  <p>(example)</p>

If an error occurs, turn off on restart balance and repeat linearization.

9. Cleaning, Repair, Maintenance and Disposal

 <p>Danger</p>	<p>Risk of injury and risk of material damage! The suspended balance is part of the lifting gear! For a safe operation please observe the following:</p> <ul style="list-style-type: none">⇒ Have carried out a regular maintenance by trained specialized staff⇒ Carry out regular maintenance and servicing, see chap. 8.3.⇒ Have the parts exchanged only by trained specialized staff.⇒ If there arose discrepancies with the safety checklist, the balance must not more be put into operation.⇒ Do not repair the suspended balance yourself. Repair may only be carried out by service partners authorized by Messrs. KERN.
--	---

9.1 Cleaning and Disposal

 <p>CAUTION</p>	<p>Damage to suspended balance!</p> <ul style="list-style-type: none">⇒ Do not use industrial solutions or chemicals (e.g. acid → embrittlement).
--	--

- ⇒ Clean the keyboard and the display with a soft cloth soaked in mild window cleaning agent.
- ⇒ Disposal of packaging and appliance must be carried out by operator according to valid national or regional law of the location where the appliance is used.

9.2 Regular maintenance and care

- ▲ The regular 3-month maintenance may only be carried out by an expert with competent knowledge of working with suspended balances. Thereby the national regulations for prevention of accidents as well as the working, operation and safety regulations of the owner-operator.
- ▲ To check the dimensions only use suitable test devices.
- ▲ The regular 12-month maintenance must only be carried out by trained specialized staff (KERN customer service).
- ▲ The results of the maintenance must be written down in the checklist (chap. 9.3).
- ▲ The additional results of the extended maintenance have to be entered in the checklist (chapter 9.3).
- ▲ The load suspension devices must be cleaned before inspection, see chap. 9.1.




Regular maintenance:

Prior to each usage	<ul style="list-style-type: none"> ▪ Check for fault-free operation of the attachment devices
Initial start-up, every 3 months or definitely after 12 500 weighing processes	<ul style="list-style-type: none"> ▪ Check all dimensions, see checklist chap. 9.3 ▪ Check the suspended balance and the used attachment device for wear and tear, such as e.g. plastic deformation, mechanical damage (unevenness), notches, striation, cracks, corrosion and torsions. ▪ Remove balance from use immediately if a reading exceeds the permitted deviation from the original reading (see checklist, chap. 9.3) or any other fault is identified.
Every 12 months or in any case after 50 000 weighing processes	<ul style="list-style-type: none"> ▪ If the enhanced maintenance has to be carried out by trained staff (KERN customer service). At this general revision all load carrying parts must be checked for gaps with magnetic powder
Every 10 years or anyway after 500 000 weighing processes	<ul style="list-style-type: none"> ▪ Replace entire suspended balance

Note


For inspection of wear and tear please refer to the drawing (See chap. 9.3) below.

Rejection criteria: Load suspension devices may no longer be used when e.g.

-  If deviations during the tests defined for maintenance were discovered.
-  The type or load rating plate is missing.
-  Load suspension devices known to have been overloaded or subject to other harmful influences may no longer be used and/or may be re-used only after inspection.

9.3 Checklist „regular maintenance“, (see chapter 9.2)

Original dimensions suspended balance (You can find these data in the documentation enclosed with the balance. Please keep this document always available)	Serial no.
	Capacity
Lifting eyes clearance k [mm]	
Date Tester	



	Clearance k	Date	Tester
Max. admitted variation	1%		
Revision prior to first use			
3 months / 12,500 x			
6 months / 25,000 x			
9 months / 37,500 x			
12 months / 50,000 x			
15 months / 62,500 x			
18 months / 75,000 x			
21 months / 87,500 x			
24 months / 100,000 x			
27 months / 112,500 x			
30 months / 125,000 x			
33 months / 137,500 x			
36 months / 150,000 x			
39 months / 162,500 x			
21 months / 87,500 x			
42 months / 175,000 x			
45 months / 187,500 x			
48 months / 200 000			
51 months / 212,500 x			
54 months / 225,000 x			
57 months / 237,500 x			
60 months / 250 000x	→ All load carrying parts have to be exchanged by a service partner authorised by KERN.		

bold letters = this maintenance work has to be carried out by a service partner authorized by KERN.

10. Enclosure

10.1 Checklist „Enhanced maintenance“ (General revision)

The enhanced maintenance has to be carried out by a service partner authorized by KERN.

Suspended balance	Model			
	Serial no.			
Interval	Magnetic particle testing for cracks lifting eyes	Date	Name	Signature
12 months / 50,000 x				
24 months / 100,000 x				
36 months / 150,000 x				
48 months / 200,000 x				
60 months / 250,000 x				
72 months / 300,000 x				
84 months / 350,000 x				
96 months / 400,000 x				
108 months/ 450 000x				
120 months/ 500 000x	➔ Replace suspended balance completely			