KERN & Sohn GmbH
Ziegelei 1
72336 Balingen-Frommern
Germany
+0049-[0]7433-9933-0
+0049-[0]7433-9933-149
info@kern-sohn.com

Installation Instructions
Interface Adapter with Cable for USB Device/Slave

KERN KUP-03

Type TYKUP-03-B
Version 1.0
2026-06
en



i	You can also find the latest version of these instructions online at https://www.kern-sohn.com/shop/de/DOWNLOADS/ under the ‘Manuals’ section.

en

Interface Adapter with Cable for USB Device/ Slave

Version 1.0 2026-06

Installation Instructions

Contents

1 General hints 2
1.1 Installation..... 2

1 General hints

	• **Only KERN KUP-adapters may be connected to the 15-pol-sub-D-connection of the balance!** • Use the KUP adapter to transfer data from the device to a PC and vice-versa.

1.1 Installation

1. Switch off the device

2. Plug the interface adapter into the KUP socket of the device.

3. Switch on the device. The interface adapter will be detected automatically by the device.

Communication parameters:

Communication parameters (baud rate, bits and parity) of balance and printer / PC must match.

Interface: USB (factory setting)	
Baud rate	9600
Data bits	8
Stop bits	1
Parity	none

USB driver:

The USB driver required for the scale is already pre-installed on devices with an up-to-date operating system.
If the system is not detected automatically, you can obtain the correct driver from the Downloads area at **www.kern-sohn.com**.

It will be recognized as a virtual COM port and will be assigned a corresponding port number.

Example (Microsoft Windows Device Manager):

