KERN & Sohn GmbH
Ziegelei 1
72336 Balingen-Frommern
Germany
+0049-[0]7433-9933-0
info@kern-sohn.com

Installation instructions
Interface adapter with cable for USB_Host/Master

KERN KUP-02
Type TYKUP-02-A
Version 1.2
2025-07
en



i	You can also find the latest version of these instructions online at: https://www.kern-sohn.com/shop/de/DOWNLOADS/ Under the heading Operating Instructions

en

Interface adapter with cable for USB_Host/ Master

Version 1.2 2025-07

Installation instructions

Cable length: 0.15 m

i	• **Only KERN KUP adapters may be connected to the 15-pin Sub-D connection of the scale!** • The KUP adapter can be used to export data from the device to a USB data carrier.
i	**The scale's settings menu is only activated when a peripheral device (e.g., a keyboard) is connected via the KUP connection.** • The menu is not available without a connected device. • As soon as a device is detected, a USB icon appears on the scale's LCD display. • The menu description can be found in the operating instructions for the respective scale.

Installation:

1. Switch off the device.
2. Plug the interface adapter into the KUP connection on the device.
3. Switch on the device. The interface adapter is automatically recognized by the device.

Protocols:

Tested protocols	Code 39, Code 39 full ASCII, Code 128, Code 128 full ASCII, Code 93, MSI, Code 11
	UPC/EAN, UPC/EAN Supplemental, UCC/EAN 128
	Interleaved 2 of 5, IATA
	Codabar, Chinese 2 of 5

Other protocols may be possible.

Accessories:

Accessory type	Model	Compatibility information
Keypad	YKX-01	Other standard keyboards with 104 or 105 key layout possible, no special keys
Numpad	YKX-02	Other 19-key numpads compatible
Barcode scanner	YKX-03	Other scanners are possible, see supported protocols