

PRODUCT BROCHURE

SAUTER FH 50K

Date: 29.04.2025

ENGLISH



Universal digital force gauge for tensile and compressive force measurements with external load cell

CONTACT

KERN & SOHN GmbH
Ziegelei 1
72336 Balingen
Germany

Phone : +49 7433 9933-0
Fax : +49 7433 9933-149
Email : info@kern-sohn.com
Web : www.kern-sohn.com



Scan here for more
information

PRODUCT SHOWCASE



DESCRIPTION

- Turnable display with backlight
- NEW: USB interface for data transfer and power supply as standard
- Data interface RS-232 as standard
- Selectable measuring units: N, kN, kgf, tf
- Peak-Hold function to capture the peak value or Track function for continuous display of measurement
- Measuring with tolerance range (limit-setting function): Upper and lower limit adjustable, in pull and push direction. The process is supported by an audible and visual signal
- Auto-Power-Off
- Internal memory for up to 10 measurement values
- Mini Statistics Kit: calculates the average result from up to 10 stored measured values, as well as min., max., n
- Tension loops and compression plates are included in delivery
- Delivered in a robust carrying case

SPECIFICATIONS

Article codes, product groups & Status information

Model article-code	FH 50K
Model-Serie	FH-M-EXT
Assortment	Sauter

Product Type	Force measurement
Product group	Digital force-measuring devices (external sensor)
Product usage type	Main article
EAN code (Model)	404576 1368620

Predecessor Model FH 50K-2019a; FH 50K-2023a

Customs tariff number 90248000

CE Label yes

Technical data - Primary

Max. Force 50 kN

Readability 10 N

Technical data - Construction

Dimension housing (W×D×H) 240×70×40 mm

Material housing plastic

Mounting thread Threaded hole M18 × 1,5

Technical data - Display

Display type LCD

Display reverse yes

Technical data - Power supply

Power supply Battery & Power supply

Battery type NiMH

Operating time (Display off) 40 h

Operating time (Display on) 24 h

Technical data - Measuring system

Units kN

Tolerance (% from Max.) 0.5%

Force direction compression;tension

Technical data - Functions

Statistic-Function yes

Limit value (Min - Max) yes

Audible ready signal yes

Interface RS-232 standard;USB-Device

Technical data - Environmental conditions

Maximum operating temperature 40 °C

Minimum storage temperature 40 °C

Technical data - Packing & Shipping

Dimensions packaging (W×D×H) 330×190×175 mm

Gross weight 4.4 kg

Net weight 2.6 kg

Shipping method Parcel service

UN number Ni-MH (UN 3496, Packing Instruction #0, Not Restricted as per Special Provision A199)

Packaging component - by weight - cardboard 210 g

Packaging component - by weight - plastics 14 g

Packaging component - by weight - styrofoam 969 g

Delivery time 1 d

Technical data - Counting data


Memory yes

Value memory - number of groups 1

Value memory - number of cells (per group) 10

FUNCTIONS

Standard



Option



ACCESSORIES

Model	Description
YKA-01	Power supply KERN YKA-01
YKA-02	Power supply adapter set KERN YKA-02
FH-A01	Interface cable FH-A01
AFM 25	Sleeve SAUTER AFM 25
FH-A04	Interface cable FH-A04

SERVICES

Model	Description
961-165	Factory calibration KERN 961-165
961-265	Factory calibration KERN 961-265
961-365	Factory calibration KERN 961-365
970-108	Warranty extension KERN (+2 years) 970-108

SPARE PARTS

Model	Description
YKA-02	Power supply adapter set KERN YKA-02

Model	Description
AFH 30	Removable battery AFH 30
FH-A02	Display overlay FH-A02
OBB-A1569	UK power supply unit KERN OBB-A1569
FS-E06	Cable SAUTER FS-E06
FS-E07	Power supply KERN FS-E07

SOFTWARES

Model	Description
AFH FD	Data Transfer Software SAUTER AFH FD
AFH LD	Data Transfer Software SAUTER AFH LD
AFH FAST	Data Transfer Software SAUTER AFH FAST

RELATED ARTICLES DATA

Model name	Max. Force	Readability
FH 5K	5 kN	1 N
FH 100K	100 kN	50 N
FH 10K	10 kN	5 N
FH 1K	1 kN	0.5 N
FH 20K	20 kN	10 N
FH 2K	2 kN	1 N
FH 50K	50 kN	10 N