



Discover more details and matching accessories online!

Modern digital weighing transmitter for the rapid recording of weighing data and forwarding it to the most varied output channels such as tablets, networks, SPS controllers, etc. – ideal for operating balances in systems or conveyors

Features

- Simply connect a weighing platform or measuring cell, integrate the digital weighing transmitter into the network and start weighing
- For rapid transfer of weighing data to connected networks, computers, etc.
- USB and RS-232 data interface standard, Power supply via USB interface
- Transfer formats are freely configurable
- Functions: Weighing, taring
- Measuring frequency 10 Hz
- Easy configuration using the software supplied
- Robust plastic die-cast housing

- **I** Suitable for wall mounting and DIN track mount
- Compatible with all KERN weighing platforms
- included with the delivery:
 - Digital weighing transmitter KERN YKV
 - USB cable incl. mains plug
 - DIN rail mounting bracket
 - Configuration software for adjusting and managing, enables the display and transfer of values, for example to a PC as well as conversion for different user programs such as SAP, Oracle etc.

Technical data

- Overall dimensions W×D×H 100×140×36 mm
- Net weight approx. 0,20 kg
- Permissible ambient temperature -10 °C/40 °C

STANDARD



YKV-02

FACTORY



Model

Standard interfaces

KERN

YKV-01

RS-232, USB

YKV-02

RS-232, USB, Ethernet