



Discover more details and matching accessories online!

Universal digital force gauge with graphic-assisted display and integrated load cell

Features

- Turnable display with backlight
- Peak-Hold function to capture the peak value or Track function for continuous display of measurement
- Metal housing for durable use in harsh environmental conditions
- Can be mounted on all SAUTER test stands up to 5 kN
- Capacity display: A bar lights up to show how much of the measuring range is still available
- Measuring with tolerance range (limit-setting function): Upper and lower limit adjustable, in pull and push direction.
The process is supported by a visual signal

- Internal memory for up to 500 measurement values
- Continuous analogue output: Linear voltage signal in dependence to the load (-2 to +2V)
- USB data interface, as standard
- Selectable measuring units: N, kN, kgf, lbf
- 1 Standard attachments: as shown
- 2 Delivered in a robust carrying case

Technical data

- Transfer rate to PC: approx. 25 measured values per second
- Measuring precision: 0,2 % of [Max]
- Overload protection: 120 % of [Max]
- Overall dimensions W×D×H 215×75×30 mm
- Thread: M6
- Rechargeable battery pack integrated, as standard, operating time up to 10 h without backlight, charging time approx. 8 h
- Net weight approx. 0,55 kg

STANDARD

OPTION

Model	Measuring range [Max]	Readability [d]	Option Calibration certificate		
			Tensile Force DAkkS accr. KERN	Compressive Force DAkkS accr. KERN	Tensile/Compressive Force DAkkS accr. KERN
SAUTER	N	N			
FL 5	5	0,002	-	-	-
FL 10	10	0,005	963-161	963-261	963-361
FL 20	25	0,01	963-161	963-261	963-361
FL 50	50	0,02	963-161	963-261	963-361
FL 100	100	0,05	963-161	963-261	963-361
FL 200	250	0,1	963-161	963-261	963-361
FL 500	500	0,2	963-161	963-261	963-361
FL 1K	1000	0,5	963-162	963-262	963-362

1 ONLY WHILE STOCKS LAST
Further calibration options on request